



Microsoft Host Guardian Service and Shielded Virtual Machines

nShield® HSM Integration Guide

2026-01-28

Member of
Microsoft Intelligent
Security Association

Table of Contents

1. Introduction	1
1.1. Product configurations.....	1
1.2. Supported nShield features.....	2
1.3. Supported nShield hardware and software versions.....	2
1.4. Requirements.....	2
1.5. More information.....	3
2. Procedures.....	4
2.1. Install and configure the nShield Security World software and nShield HSM	4
2.2. Install and register the nShield CNG	5
2.3. Install the Host Guardian Service in a new forest.....	11
2.4. Generate certificates	15
2.5. Initialize the Host Guardian Service	21
2.6. Configure the Guarded Host	23
2.7. Configure attestation on the Guardian Server.....	28
2.8. Configure attestation on the Guarded Host.....	29
3. Remote Administration	31
4. Windows 2025 support.....	32
5. Additional resources and related products.....	34
5.1. nShield HSMs.....	34
5.2. nShield as a Service.....	34
5.3. Entrust products	34
5.4. nShield product documentation.....	34

Chapter 1. Introduction

The Entrust nShield HSMs secure keys that encrypt and sign the protected VMs. The keys are stored in an encrypted state on the Host Guardian Server (HGS).

The Guarded Host provides a trusted server and environment in which to create and run the Shielded VMs. The HGS attests the trustworthiness of a particular Guarded Host before releasing the relevant protection key used to unlock (decrypt), the virtual machine.

The HGS only releases the decryption key for the Shielded VM when it is satisfied that the condition of the VM matches a known clean state and that the VM has not been tampered with. This is achieved by providing evidence to attest to the VM's integrity via a certificate that is also provided by the HGS.

Attestation process for running Shielded VMs on a Hyper-V Guarded Host:

1. The Guarded Host requests a key to allow it to run the Shielded VM.
2. The HGS receives the request but does not trust that the request comes from a legitimate host.
3. The Guarded Host sends its declaration of health information, a known state conferred upon the host by the HGS in the initial set-up of the Hyper-V host.
4. The HGS responds with a certificate of health to the host.
5. The host makes another request, which includes the certificate to the HGS.
6. The HGS returns the encrypted key to the virtualized security area of the Guarded Host, allowing the VM to run.

1.1. Product configurations

Entrust has successfully tested nShield HSM integration with Windows Hyper-V feature in the following configurations:

Product	Version
Guardian Server Base OS	Windows Server 2022 Datacenter
Guarded Host Base OS	Windows Server 2022 Datacenter



Host Guardian Service on Windows Server 2025 feature is deprecated and unsupported. If you need HGS, you must use Windows Server 2022 Datacenter or earlier.

1.2. Supported nShield features

Entrust has successfully tested nShield HSM integration with the following features:

Feature	Support
Operator Card Set (OCS)	Yes
Softcard Protection	Yes
Module	Yes

1.3. Supported nShield hardware and software versions

Entrust has successfully tested integrations the following hardware and software versions:

Product	Security World Software	Firmware	Image
Connect XC	13.6.14	12.72.1, 12.72.3 and 12.72.4 (FIPS 140-2 certified)	13.6.14
nShield 5c	13.6.14	13.4.5 (FIPS 140-3 certified)	13.6.14

1.4. Requirements

Familiarize yourself with the Microsoft Hyper-V and Guarded Hosts documentation and set-up process.

Before installing these products, read the associated nShield HSM *Installation Guide* and *User Guide*.

This guide assumes familiarity with the following:

- The importance of a correct quorum for the Administrator Card Set (ACS).
- Whether Operator Card Set (OCS) protection or Softcard protection is required.
- If OCS protection is to be used, a 1-of-N quorum must be used.
- Whether your Security World must comply with FIPS 140 Level 3 or Common Criteria standards. If using FIPS 140 Level 3, it is advisable to create an OCS for FIPS authorization. The OCS can also provide key protection for the Vault master key. For information about limitations on FIPS authorization, see the *Installation Guide* of the nShield HSM.



Entrust recommends that you allow only unprivileged connections unless you are performing administrative tasks.

- Whether to instantiate the Security World as recoverable or not.
- Network environment set-up, via correct firewall configuration with usable ports: 9004 for the HSM and 9005 for remote administration.

1.5. More information

For more information contact your sales representative or Entrust nShield Support, <https://nshieldsupport.entrust.com>.



Access to the Entrust Support Portal is available to customers under maintenance. To request an account, contact nshield.support@entrust.com.

Chapter 2. Procedures

The following steps summarize the integration procedure.

Guardian Server:

1. [Install and configure the nShield Security World software and nShield HSM.](#)
2. [Install and register the nShield CNG.](#)
3. [Install the Host Guardian Service in a new forest.](#)
4. [Generate certificates.](#)
5. [Initialize the Host Guardian Service.](#)

Guarded Host:

1. [Configure the Guarded Host.](#)
2. [Configure attestation on the Guardian Server.](#)
3. [Configure attestation on the Guarded Host.](#)



For this guide both the Guardian Server and Guarded Host were implemented on virtual machines. Microsoft recommends installing the Host Guardian Service role on a physical machine for security purposes.



The Host Guardian Service should be installed in a dedicated Active Directory forest. Ensure the Guardian Server and Guarded Host are not joined to a domain.

2.1. Install and configure the nShield Security World software and nShield HSM

Install the HSM using the instructions in the *Installation Guide* for the nShield HSM.

To install the Security World software and create the Security World:

1. Install the latest version of the Security World software as described in the *User Guide* for the HSM. Entrust recommends that you uninstall any existing Security World software before installing the new Security World software.
2. Add the Security World utilities path `C:\Program Files\nCipher\nfast\bin` to the Windows system path.
3. Open the firewall port 9004 for the HSM connections.
4. Install the nShield Connect HSM locally, remotely, or remotely via the serial console.

See the following nShield Support articles and the *Installation Guide* for the HSM:

- [How to locally set up a new or replacement nShield Connect](#)
- [How to remotely set up a new or replacement nShield Connect](#)
- [How to remotely set up a new or replacement nShield Connect XC Serial Console model](#)



Access to the Entrust nShield Support Portal is available to customers under maintenance. To request an account, contact nshield.support@entrust.com.

5. Open a command window and run the following to confirm that the HSM is **operational**:

```
> enquiry
Server:
  enquiry reply flags  none
  enquiry reply level  Six
  serial number       530E-02E0-D947
  mode                operational
...
Module #1:
  enquiry reply flags  none
  enquiry reply level  Six
  serial number       530E-02E0-D947
  mode                operational
...
```

6. Create your Security World if one does not already exist or copy an existing one. Follow your organization's security policy for this. The Security World can also be created later, when configuring the CNG provider via its GUI, see [Install and register the nShield CNG](#). Skip the next step if doing so.
7. Confirm that the Security World is **usable**:

```
>nfkminfo
World
  generation  2
  state       0x37270008 Initialised Usable ...
...
Module #1
  generation  2
  state       0x2 Usable
...
```


2.2. Install and register the nShield CNG

It is necessary to install and register the nShield Cryptography API: Next Generation (CNG) provider on the Guardian Server. This can be done using either the command line or the


CNG Configuration wizard.

Before proceeding, check that no legacy providers are installed.

1. Select the **Start** button to access all applications. Look for the recently installed nShield utilities.
2. Double-click the **CNG Configuration** wizard and run it as Administrator.




The nShield CNG Providers Configuration Wizard starts.



3. On the **Welcome** panel, select **Next**.

The **Enable HSM Pool Mode** panel appears.




4. If you intend to use multiple HSMs in a failover and load-sharing capacity, select **Enable HSM Pool Mode for CNG Providers**. If you do, you can only use module protected keys.



Module protection does not provide conventional 1 or 2 factor authentication. Instead, the keys are encrypted and stored as an application key token, also referred to as a Binary Large Object (blob), in the `kmdata/local` directory of the HGS server.

5. Select **Next**.

The **Initial setup** panel appears:



- Select **Use the existing security world** if you already have a Security World that you intend to use. The corresponding `world` and `module_XXXX-XXXX-XXXX` files must be present in the `%NFAST_KMDATA%\local` directory. Be prepared to present the

quorum of Administrator cards.

- Select **Create a new Security World** if you do not currently have a Security World or would like to create a new Security World.



For the purposes of this guide, an existing Security World is used. For instructions on how to create and configure a new Security World, see the *Installation Guide* and *User Guide* for your HSM.

6. Select **Next**.

The **Set Module States** panel appears.

nShield CNG Providers Configuration Wizard

Set Module States
Ensure modules are in the correct state before you proceed.

The following modules are available in your system:

Module ID	Mode	State
1	operational	usable
2	operational	foreign

At least one module is usable in the current world. Click Next to continue with this world. Or reset module 2 to the initialization state to enable you to restore your security world to uninitialized nShield modules.

Refer to the user guide for details of how to put your nShield module in the initialization state. If you need to power down your computer, select the tickbox below and then restart the wizard on boot up to continue the installation.

☐ The machine must be switched off to change the hardware state.

< Back Next > Cancel

7. Select the desired HSM among those available.

8. Select **Next**.

The **Key Protection Setup** panel appears.

nShield CNG Providers Configuration Wizard

Key Protection Setup
Set up the private key-protection method.

Select the default method that will be used to protect private keys generated by the CNG Key Storage Provider.

If softcard or OCS protection is selected, the choice will be offered on the next page whether to use an existing token or create a new one.

☐ Module protection (requires no extra cards but is less secure).

☐ Softcard protection (unavailable in HSM Pool Mode).

☒ Operator Card Set protection (unavailable in HSM Pool Mode).

☐ Allow any protection method to be selected in the GUI when generating.

< Back Next > Cancel

9. Select the required protection method.

For the purposes of this guide, **Operator Card Set** is used. You can choose **Module Protection** or **Softcard Protection** instead.

10. Select **Next**.

The **Token for Key Protection** panel appears.

The screenshot shows the 'Token for Key Protection' panel of the 'nShield CNG Providers Configuration Wizard'. The panel has a title bar with a close button (X) and the Entrust logo. Below the title, it says 'Token for Key Protection' and 'Select the token that will be used to protect new keys, or create a new token.' The main area is divided into two sections: 'Current Operator Card Sets:' and 'Operator Card Set Token Information:'. The 'Current Operator Card Sets:' section shows 'No tokens found.' The 'Operator Card Set Token Information:' section has fields for 'Name:', 'Token hash:', 'Sharing parameters:', 'Timeout:', and 'Currently protecting:'. Below these sections, there are checkboxes for 'Create a new Operator Card Set name' (checked), 'Card set has a time-out' (unchecked), 'Persistent' (checked), and 'Usable remotely' (checked). There are also input fields for 'MSAuthenticode' (the name), 'Number of cards required (K): 1', and 'Total number of cards (N): 1'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

11. Enter the OCS name, K and N values, select **Persistent**, and select **Usable remotely**.
12. Select **Next**.

You must now present the cards.


13. First present the ACS to the HSM.

Then remove the ACS and insert a blank Operator Card in the HSM. On the **Insert Next Card** screen enter a name for the OCS and corresponding passphrase.

The screenshot shows the 'Insert Next Card' panel of the 'nShield CNG Providers Configuration Wizard'. The panel has a title bar with a close button (X) and the Entrust logo. Below the title, it says 'Insert Next Card' and 'Insert the next card in the sequence.' The main area is divided into two sections: 'Preparing to write Operator Card number 1 of 1. Insert a blank card in module 1.' and 'Name of card: MSAuthenticode'. Below these sections, there are checkboxes for 'Card requires a pass phrase' (checked). There are also input fields for 'Enter pass phrase:' and 'Re-enter pass phrase:'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

14. Select **Next** and repeat until all cards in the OCS have been presented.
15. Select **Finish**.

The nShield CNG providers will now be installed and the Key Storage Provider will be registered.



After this process completes, the **Finished Registering the nShield CNG Providers** panel appears.



16. Open a command window as Administrator and run the following command to confirm the KSP has been successfully registered:

```
> cnglist.exe --list-providers
Microsoft Key Protection Provider
Microsoft Passport Key Storage Provider
Microsoft Platform Crypto Provider
Microsoft Primitive Provider
Microsoft Smart Card Key Storage Provider
Microsoft Software Key Storage Provider
```

```
Microsoft SSL Protocol Provider
Windows Client Key Protection Provider
nCipher Primitive Provider
nCipher Security World Key Storage Provider
```

Look for the **nCipher Security World Key Storage Provider** entry.


17. Run the following from PowerShell after the Host Guardian Service has been installed:

```
> Show-DnsServerKeyStorageProvider
Microsoft Software Key Storage Provider
nCipher Security World Key Storage Provider
Microsoft Passport Key Storage Provider
Microsoft Platform Crypto Provider
Microsoft Smart Card Key Storage Provider
```

18. Check that the registry also shows the **nCipher Security World Key Storage Provider**:

```
HKEY_LOCAL_MACHINE\SYSTEM\ControlSet001\Control\Cryptography\Providers\nCipherSecurityWorldKeyStorageProvider
```

For example:



2.3. Install the Host Guardian Service in a new forest

This section describes how to install the Host Guardian Service in a new Active Directory forest:

- Add the Host Guardian Server role using the Server Manager GUI.
- Add the Host Guardian Server role using PowerShell.
- Install the Host Guardian Service.

Microsoft has documented the full process in <https://technet.microsoft.com/en-us/windows-server-docs/security/guarded-fabric-shielded-vm/guarded-fabric-deploying-hgs-overview>.


2.3.1. Add the Host Guardian Server role using the Server Manager GUI



You can also add the Host Guardian Server role using PowerShell, see [Add the Host Guardian Server role using PowerShell](#).


To add the Host Guardian Server using the Server Manager GUI:

1. Open **Server Manager** and under **Manage**, select **Add Roles and features**.



The **Add Roles and Features Wizard** starts.

2. Select **Next** until you reach the **Select destination server** panel.
3. On the **Select destination server** panel, select the Guardian Server. For example:




4. Select **Next**.

The **Select server roles** panel appears.


5. Select **Host Guardian Service**.

The **Add features that are required for Host Guardian Service?** dialog appears.



6. In the dialog, select **Add Features** and select **Next**.

7. Select **Next** multiple times until the install for the **Select role services** panel for Web Server Role (IIS) appears.




8. Select **Next** to install IIS and then select **Install**.

After the installation completes, a server restart is required.

After the role has been added, you are prompted to continue with **Post-deployment Configuration** by promoting the server to a domain controller. This is shown by expanding the notification flag in the **Server Manager Dashboard**.



Do not promote to domain controller at this time. The server will be promoted as part of the HGS installation process below.



2.3.2. Add the Host Guardian Server role using PowerShell



You can also add the Host Guardian Server role using the Server Manager GUI, see [Add the Host Guardian Server role using the Server Manager GUI](#).

To add the Host Guardian Server role using PowerShell:

1. Start PowerShell in an elevated Admin mode.
2. Run the following command:

```
Install-WindowsFeature -Name HostGuardianServiceRole -IncludeAllSubFeature -IncludeManagementTools -Restart
```



Do not promote to domain controller at this time. The server will be promoted as part of the HGS installation process below.

2.3.3. Install the Host Guardian Service

To install the Host Guardian Service:

1. Launch PowerShell as Administrator.
2. Run the script (below) to install the Host Guardian Service and configure its domain.

```
$hgsDomainName = "hgs.com"

$adminPassword = ConvertTo-SecureString -AsPlainText "xxxxxxxxxx" -Force

Install-HgsServer -HgsDomainName $hgsDomainName -SafeModeAdministratorPassword $adminPassword -Restart
```


The password you specify here will only apply to the Directory Services Repair Mode

password for Active Directory. It will not change your admin account's password.

You may provide any domain name of your choosing for `-HgsDomainName`.

The server will reboot after executing the above script.

The Host Guardian Service domain is created.



2.4. Generate certificates

The following sections describe how to generate certificates:

1. [Generate certificates using the nShield key storage provider.](#)
2. [Confirm certificates and keys.](#)

2.4.1. Generate certificates using the nShield key storage provider

The HGS requires certificates and associated keys.

Keys are used for "attestation", one of the two services that run as part of HGS, to affirm the health of the Guarded Hosts and the associated Hyper-V virtual machines.

Other keys called Transport Keys (TKs) are used for "Key Protection Service" (KPS), to unlock and run the Shielded VMs on positively attested Guarded Hosts.

Run `certutil -store my` for the certificates currently available in the machine store. For example:

```
>certutil -store my  
my "Personal"  
CertUtil: -store command completed successfully.
```



It is possible to use conventionally backed Certificates from a

Certificate Authority and import these into the HSM Security World, but this is not within the scope of this document.

The following sections generate these keys and certificates using the nShield KSP.

2.4.1.1. Generate encryption certificate

To generate an encryption certificate:

1. Launch PowerShell as Administrator.
2. Run the following script:

```
$cngProviderName = "nCIPHER Security World Key Storage Provider"


$subjectName = "HGS Encryption Certificate"

$friendlyName = "HGS_Encryption_SelfCert"

# $locationName = "Cert:\CurrentUser\My"
$locationName = "Cert:\LocalMachine\My"


New-SelfSignedCertificate -Subject $subjectName -FriendlyName $friendlyName -CertStoreLocation
$locationName -Provider $cngProviderName -KeyExportPolicy NonExportable
```

The **nCipher Key Storage Provider - Create key** wizard appears.



3. In the **Create new key** panel, select **Next**.


The **Select a method to protect new key** panel appears.



If you are using a FIPS 140-2 Level 3 Security World, you will need to present an OCS for FIPS authorization, irrespective of your chosen protection method.


1. Select the **Operator Card Set protection** and select **Next**.

The **Select token to protect key with** panel appears.




2. Present the OCS created before and select **Next**.

The **Choose modules you wish to load the keys onto** panel appears.




3. Select the required HSM and select **Add** to move the HSM to the Included modules list. In this example, two HSMs are available.
4. Select **Finish**.

A passphrase dialog appears.



5. Enter the passphrase for the OCS and select **Next**.

An OCS status dialog appears.



6. Select **Finish** after the card reading is completed.

The output will look like the following:

```
PSParentPath: Microsoft.PowerShell.Security\Certificate::LocalMachine\My

Thumbprint                               Subject
-----
4AC08FF75C0C311CF4CF3591336FD85F0BEB539A  CN=HGS Encryption Certificate
```

2.4.1.2. Generate signing certificate

To generate a signing certificate:

1. Launch PowerShell as Administrator.
2. Run the following script:

```
$cngProviderName = "nCipher Security World Key Storage Provider"

$subjectName = "HGS Signing Certificate"

$friendlyName = "HGS_Signing_SelfCert"

# $locationName = "Cert:\CurrentUser\My"
$locationName = "Cert:\LocalMachine\My"

New-SelfSignedCertificate -Subject $subjectName -FriendlyName $friendlyName -CertStoreLocation
$locationName -Provider $cngProviderName -KeyUsageProperty Sign -KeyExportPolicy NonExportable
```

3. Select the protection method, present the OCS, select the HSM, and enter the passphrase when prompted. This is similar process to the previous section.



If you are using a FIPS 140-2 Level 3 Security World, you will need to present an OCS for FIPS authorization, irrespective of your chosen protection method.

+ The output will look like the following:

+

```
PSParentPath: Microsoft.PowerShell.Security\Certificate::LocalMachine\My

Thumbprint                               Subject
-----
586F6B0A44C4F498525965B41B0570F365E4577C  CN=HGS Signing Certificate
```

2.4.2. Confirm certificates and keys

When keys are generated by the HSM:

- The key's blobs are stored in the `C:\ProgramData\nCipher\Key Management Data\local` directory.
- On the HGS the certificates are in the `\LocalMachine\My` store directory.

To verify that the certificates are in the correct location using PowerShell:

```
> Get-ChildItem Cert:\LocalMachine\My -DnsName hgs*

PSParentPath: Microsoft.PowerShell.Security\Certificate::LocalMachine\My

Thumbprint                               Subject
-----
586F6B0A44C4F498525965B41B0570F365E4577C  CN=HGS Signing Certificate
4AC08FF75C0C311CF4CF3591336FD85F0BEB539A  CN=HGS Encryption Certificate
```

To verify the certificates via the command line, use `certutil` (see below). Present the OCS, select the HSM, and enter the passphrase when prompted. For example:

```
C:\Users\Administrator>certutil -store my
my "Personal"
===== Certificate 0 =====
Serial Number: 37dbec23d4a2b4a74be186edc9f7bd0a
Issuer: CN=HGS Signing Certificate
NotBefore: 1/7/2026 11:23 AM
NotAfter: 1/7/2027 11:43 AM
Subject: CN=HGS Signing Certificate
Signature matches Public Key
Root Certificate: Subject matches Issuer
Cert Hash(sha1): 586f6b0a44c4f498525965b41b0570f365e4577c
  Key Container = te-3a421e61-fc7d-4af4-9774-a172e94949a0
  Provider = nCipher Security World Key Storage Provider
Private key is NOT exportable
Signature test passed
```

```
===== Certificate 1 =====
Serial Number: 18f94a311e2dc3804ec0f6cc736cf979
Issuer: CN=HGS Encryption Certificate
NotBefore: 1/7/2026 11:21 AM
NotAfter: 1/7/2027 11:41 AM
Subject: CN=HGS Encryption Certificate
Signature matches Public Key
Root Certificate: Subject matches Issuer
Cert Hash(sha1): 4ac08ff75c0c311cf4cf3591336fd85f0beb539a
Key Container = te-a126bc32-d971-48aa-852e-154bfd403206
Provider = nCipher Security World Key Storage Provider
Private key is NOT exportable
ERROR: Could not verify certificate public key against private key
CertUtil: -store command completed successfully.
```

Make a note of the **Cert Hash(sha1)** values for the signing certificate and the encryption certificate. You will use these in the next section.

2.5. Initialize the Host Guardian Service

To initialize the Host Guardian Service:

1. Launch PowerShell as Administrator.
2. Run the following script:

```
$hgsServiceName = "HGS"

$encryptionCertificateThumbprint = "4ac08ff75c0c311cf4cf3591336fd85f0beb539a"

$signingCertificateThumbprint = "586f6b0a44c4f498525965b41b0570f365e4577c"

Initialize-HgsServer -HgsServiceName $hgsServiceName -EncryptionCertificateThumbprint
$encryptionCertificateThumbprint -SigningCertificateThumbprint $signingCertificateThumbprint -TrustHostKey
```

In this script:

- For **hgsServiceName**, insert a name of your choosing for the HGS node. This name will be the distributed network name of the cluster and should not be fully qualified. For example, enter **HGS** if you want the FQDN to be configured as **HGS.<domain>.<com>**.
- For **encryptionCertificateThumbprint**, insert the encryption certificate hash from [Confirm certificates and keys](#).
- For **signingCertificateThumbprint**, insert the signing certificate hash from [Confirm certificates and keys](#).

Here is the output:


```
WARNING: The names of some imported commands from the module 'BitLocker' include unapproved verbs that
might make them
```

```


less discoverable. To find the commands with unapproved verbs, run the Import-Module command again with the
Verbose
parameter. For a list of approved verbs, type Get-Verb.
LogPath: C:\Windows\Logs\HgsServer\260109072007\MS22-HG-SERVER
WARNING: Ensure that service account 'interophgs\HGSSVC_EAF46$' has read access to the private key of
certificate with
thumbprint 'A84663090FD379A7C17A9E104B64BB02E5EAE24F', and that that the private key is both present and
accessible on
all Host Guardian Service servers.
WARNING: Ensure that service account 'interophgs\HGSSVC_EAF46$' has read access to the private key of
certificate with
thumbprint '5FE1988CF4C50608093538D3A2DCA8881B5C284E', and that that the private key is both present and
accessible on
all Host Guardian Service servers.

```


3. Make a note of the name of the service account that is created during this process.
4. Ensure the service account created above has rights to the HSM backed keys:
 - a. Launch the IIS Manager and select **Application Pools** and note the **Identity** under which the **KeyProtection app pool** is running. For example:



- b. Run the Local Machine Certificate Management Console `certlm.msc`. Locate the encryption certificate under the **Personal** folder.
- c. Right-click and select **All tasks > manage Private keys**.
- d. Present the OCS, select the HSM, and enter the passphrase when prompted.
- e. Add the service account above to the list of Groups and Users permitted to manage the private keys.
- f. Select **Add > Object Types > Service Accounts**, then select **OK**.
- g. Under **Enter the object names to select**, type the account name. The default is **HGSSVC**.
- h. Select **Check Names**.



- i. Give the service account Read access to the private keys for the certificate. To do this, select **Advanced**, select the user account, then select **Edit**. For example:




- j. Repeat the process for the signing certificate.


2.6. Configure the Guarded Host

The Guarded Host is the host server for the Hyper-V virtual machines that will become Shielded VMs. The Guarded Host will require attestation from the HGS before its shielded VMs will be allowed to run. For the purpose of this guide, the Guarded Host was implemented on a ESXi 7.1 VM.

1. On the ESXi Hypervisor, edit VM settings.
2. On the **Virtual Hardware** tab, ensure that **Expose hardware assisted virtualization to guess OS** is selected. For example:



3. On the **VM Options** tab, ensure that **Virtualization Based Security** is enabled.



4. Ensure that the following roles are installed:

- AD DS
- DNS
- AD LDS.


This is required for **netdom.exe** which is used to establish one-way trust from the HGS to the Fabric domain.

- Hyper-V.



This should include the Host Guardian support feature.


5. Determine the status of the required roles by selecting **Add Roles and Features Server Selection > Server Roles**. The installed features are selected. For example:




6. Ensure the hypervisor-protected code integrity (HVCI) is enabled, see [Enable virtualization-based protection of code integrity](#).

7. Promote the DNS server as normal if installing it for the first time.

- a. You will notice that after installing all the roles, the DNS configuration still needs to happen.



- b. Select **Promote this server to a domain controller**.



- c. On the **Deployment Configuration** pane, select **Add a new domain to an existing forest**.

- i. For Domain type: **Tree Domain**.
 - ii. Forest Name: **hgs.com**.
 - iii. New Domain Name: **guardedhost.com**
 - iv. Supply the **hgs\Administrator** password, by selecting **Change**.
- d. Select **Next**.
- e. On the **Domain Controller Options** pane, enter the **DSRM** password.
- f. On the **DNS Options** pane, select **Next**.
- g. On the **Additional options** pane, take the default and select **Next**.
- h. On the **Paths** pane, select **Next**
- i. On the **Review Options** pane, select **Next**.
- j. On the **Prerequisite Check** pane, if all Prerequisite checks passed, select **Install**.

If the installation is successful, the server restarts.

8. Add the Host Guardian Server DNS as a conditional forwarder:

- a. Open PowerShell as Administrator
- b. Run the following:

```
$hgsDomainName = "hgs.com"

$ipAddressHGSServer = "xxx.xxx.xxx.xxx"

Add-DnsServerConditionalForwarderZone -Name $hgsDomainName -ReplicationScope "Forest" -MasterServers
$ipAddressHGSServer
```



This can also be performed from the DNS Manager GUI.

9. Set the Guarded Host domain to trust the Guardian Server domain:

- a. Open PowerShell as Administrator.
- b. Run the following command:

```
> netdom trust guardedhost.com /domain:hgs.com /user:hgs\Administrator /passwordd:nCipher123! /add

The command completed successfully.
```

10. Generate a Guardian Host key automatically or select an existing certificate.

Alternatively, you can also use a certificate generated by the nShield HSM as on the Guardian Server.

- a. Open PowerShell as Administrator.
- b. Run the following command:

```
> Set-HgsClientHostKey
```

- c. Get the public half of the key to provide the HGS server.

You can also provide a **.cer** file that contains the public half of the key. Note that the HGS is only used to store and validate the public key. No certificate information is stored on the HGS and neither the certificate chain nor the expiration date is validated by the HGS.

Open PowerShell as Administrator and run:

```
> Get-HgsClientHostKey -Path "C:\Users\Administrator\Documents\HostGuardianHst-HostKey.cer"

Directory: C:\Users\Administrator\Documents

Mode                LastWriteTime         Length Name
----                -
-a-----         1/8/2026  11:23 AM           830 HostGuardianHst-HostKey.cer
```

- d. Copy the listed certificate file to the Guardian Server using the method of your choice. You will add this certificate to the attestation service.
11. Create a new Global security group to identify the Guarded Hosts that will run the shielded VMs.
 - a. Open the Server Manager and select **Tools > Active Directory Users and Computers**.
 - b. Expand the domain.
 - c. Right-click **Users**, select **New > Group**, and enter the group name.

New Object - Group

Create in: guardedhost.com/Users

Group name:
Guarded Hosts

Group name (pre-Windows 2000):
Guarded Hosts

Group scope

☐ Domain local

☒ Global

☐ Universal


Group type

☒ Security

☐ Distribution

OK Cancel

The security group is created. For example:



12. Get the Security Identifier (SID) of the security group created above.

- a. Open PowerShell as Administrator.
- b. Run the following command:

```
> Get-ADGroup "Guarded Hosts"

DistinguishedName : CN=Guarded Hosts,CN=Users,DC=guardedhost,DC=com
GroupCategory     : Security
GroupScope        : Global
Name              : Guarded Hosts
ObjectClass       : group
ObjectGUID        : b914cb31-fe5f-4d10-be70-60bbcf95243
SamAccountName    : Guarded Hosts
SID               : S-1-5-21-2491135030-878028546-2245137482-1104
```

2.7. Configure attestation on the Guardian Server

Perform the following on the Guardian Server:

1. Register the global security group created in the Guarded Host with the Guardian Server as an Attestation Host Group:
 - a. Copy the group name and SID from the previous step.
 - b. Open PowerShell as Administrator and run the commands:

```
$guardedHostName = "Guarded Hosts"
$SID = "S-1-5-21-2491135030-878028546-2245137482-1104"
Add-HgsAttestationHostGroup -Name $guardedHostName -Identifier $SID
```

The command line and output look like the following:

```
WARNING: The current attestation operation mode is: "HostKey". Any "AD" mode specific changes made or
content returned
```

will not take effect until the attestation operation mode is changed to "AD".
S-1-5-21-2491135030-878028546-2245137482-1104:Guarded Hosts

2. Confirm that the Guarded Host group was added:

> Get-HgsAttestationHostGroup

WARNING: The current attestation operation mode is: "HostKey". Any "AD" mode specific changes made or content returned will not take effect until the attestation operation mode is changed to "AD".

Name	Identifier
-----	-----
Guarded Hosts	S-1-5-21-2491135030-878028546-2245137482-1104

Notice the returned friendly name and SID.

This completes the process of configuring the HGS cluster.

3. Add the Guardian Host certificate copied above to the attestation service. The certificate was copied to **C:\Users\Administrator\Documents**.
 - a. Open PowerShell as Administrator.
 - b. Run the following command:

> Add-HgsAttestationHostKey -Name HostGuardianHst-HostKey -Path
"C:\Users\Administrator\Documents\HostGuardianHst-HostKey.cer"

Name	PublicKey
-----	-----
HostGuardianHst-HostKey	System.Security.Cryptography.X509Certificates.PublicKey

4. The fabric Administrator needs to provide two URLs from the Guardian Server to the Guarded Host. Obtain these URLs by executing the following command:

> Get-HgsServer

Name	Value
-----	-----
AttestationOperationMode	HostKey
AttestationUrl	{http://hgs.hgs.com/Attestation}
KeyProtectionUrl	{http://hgs.hgs.com/KeyProtection}

2.8. Configure attestation on the Guarded Host

Perform the following on the Guarded Host:

1. Configure the Key Protection and Attestation URLs.
2. Open PowerShell as Administrator and run the following cmdlet.

> Set-HgsClientConfiguration -AttestationServerUrl 'http://hgs.hgs.com/Attestation' -KeyProtectionServerUrl

```
'http://hgs.hgs.com/KeyProtection'
```

```
IsHostGuarded      : True
Mode                : HostGuardianService
KeyProtectionServerUrl : http://hgs.hgs.com/KeyProtection
AttestationServerUrl  : http://hgs.hgs.com/Attestation
AttestationOperationMode : HostKey
AttestationStatus     : Passed
AttestationSubstatus  : NoInformation
FallbackKeyProtectionServerUrl :
FallbackAttestationServerUrl :
IsFallbackInUse      : False
```

3. Copy the attestation server URL and key protection server URL from the previous step.

You should now be able to create shielded VM templates as per Microsoft guidelines using either Virtual Machine Manager (VMM) or Windows Azure Pack.

Chapter 3. Remote Administration

Remote Administration uses smartcards and a Trusted Verification Device. Before any smartcard can be used, it must be registered in the list of acceptable cards.

For added security, each smartcard's unique serial number can be entered. The serial number is the 16-digit number found at the bottom of the card. You can allow any smartcard with the wildcard character (*).

Save the **cardlist** and close the **cardlist** configuration file.

Initially these smartcards will form your Administrator Card Set. For information about ACS, see the *User Guide* for your HSM.

The cardlist configuration file can be found in: **C:\ProgramData\nCipher\Key Management Data\config\cardlist**.



By default, **ProgramData** is hidden. In Windows Explorer, select **View**, then select **Hidden items**.

Example cardlist configuration file:

```
# This is the cardlist file, which contains the serial numbers of any
# Remote Administration Ready Smartcards that a system administrator
# has permitted to be used.
These serial numbers are printed on the
# face of the smartcards
# Examples of valid 16 digit serial numbers:
# XXXXXXXX-XXXXXXXXXX
# XXXXXXXXXXXXXXXXXXXX
# XXXX-XXXX-XXXX-XXXX
# To permit any cards presented to be used:
# *
# The default configuration file has no cards listed, this means
# that all cards will be rejected by default.
*
```

Chapter 4. Windows 2025 support

Host Guardian Service on Windows Server 2025 feature is deprecated and unsupported. If you need HGS, you must use Windows Server 2022 Datacenter or earlier.

When you attempt to Configure attestation on the Guarded Host by performing the following:

```
Set-HgsClientConfiguration -AttestationServerUrl URL -KeyProtectionServerUrl URL
```

The following error occurs:

```
Set-HgsClientConfiguration -AttestationServerUrl 'https://hgs.hgs.local/Attestation' -KeyProtectionServerUrl 'https://hgs.hgs.local/KeyProtection'

Invoke-CimMethod : Using this operation in SHS mode is unsupported for this version of Windows.

At C:\WINDOWS\system32\WindowsPowerShell\v1.0\Modules\HgsClient\HgsClient.psm1:449 char:18
+ ...          (Invoke-CimMethod -Namespace Root\Microsoft\Windows\Hgs -C ...
+ ~~~~~
+ CategoryInfo          : NotSpecified: (Root\Microsoft\...ntConfiguration:String) [Invoke-CimMethod], Cim
Exception
+ FullyQualifiedErrorId : Windows System Error -2147467259,Microsoft.Management.Infrastructure.CimCmdlets."
```

The error **Invoke-CimMethod : Using this operation in SHS mode is unsupported for this version of Windows** indicates that Windows Server 2025 has changed or removed support for classic Host Guardian Service (HGS) Shielded VM mode, also referred to internally as SHS (Shielded Host Support).

Windows Server 2025 introduces major security platform changes:

- Host Guardian Service (HGS) is deprecated
- Shielded VMs are being replaced by Secured-core / vTPM / VBS models
- Several PowerShell cmdlets under HgsClient and HgsServer are retired or non-functional

This is why these commands work on Windows Server 2019 and Windows Server 2022 but they fail on Windows Server 2025 where Microsoft has removed or blocked SHS/HGS functionality. The command fails because internally uses CIM calls to **Root\Microsoft\Windows\Hgs**. This namespace still exists but several methods are stubbed or disabled. HGS client mode (**-Mode HostGuardianService**) is no longer supported. Windows logs this internally as **SHS mode is unsupported for this version of Windows**.

This is a Windows OS behavior change not an nShield integration issue.

Microsoft is shifting away from HGS and shielded VMs and the HGS model is now obsolete.

It is replaced by:

- vTPM provisioning through Host Key Attestation
- Secured-core server
- VBS + HVCI
- Azure-based attestation models
- Key release through TPM-backed trust

For TPM-based attestation, Windows server 2025 supports:

- TPM 2.0 attestation
- vTPM provisioning via Hyper-V
- Secure Launch
- Key release policies integrated with VBS

Chapter 5. Additional resources and related products

5.1. nShield HSMs

5.2. nShield as a Service

5.3. Entrust products

5.4. nShield product documentation