



Palo Alto Networks Firewall to Next Generation

nShield® HSM Integration Guide

2025-09-16

Table of Contents

1. Introduction	1
1.1. Product configurations.....	1
1.2. Requirements	2
1.3. Considerations for keys.....	3
2. Procedures	5
2.1. Prepare the RFS and the HSM(s)	5
2.2. Set up connectivity between the Firewall, the HSM, and the RFS	5
2.3. Encrypt the master key using the HSM.....	12
2.4. Store the key used in SSL/TLS decryption	14
2.5. Adding more HSMs	19
3. Additional resources and related products.....	23
3.1. nShield Connect	23
3.2. nShield as a Service.....	23
3.3. Entrust products.....	23
3.4. nShield product documentation.....	23

Chapter 1. Introduction

This Integration Guide describes the deployment of a Palo Alto Networks Firewall with a nShield HSM. The HSM securely generates and stores digital keys. It provides both logical and physical protection from non-authorized use and potential adversaries. The HSM-Firewall integration provides security by protecting the master keys. The HSM can also provide protection for the private keys used in SSL/TLS decryption, both in SSL forward proxy and SSL inbound inspection.

This guide assumes that there is no existing nShield Security World. For instructions to create a Security World, see the *User Guide* for your HSM. In situations in which a Security World already exists, parts of this integration guide can still be used for the generation and subsequent storage of keys.

The benefits of using an nShield HSM with the Palo Alto Networks Firewall include:

- Secure encryption and storage of the firewall master key and private keys.
- FIPS 140 Level 3 validated hardware.

1.1. Product configurations

Entrust has successfully tested nShield HSM integration with the Palo Alto Networks Firewall in the following configurations:

- PAN-OS v12.1.2 with Entrust Security World v13.6.3, the version integrated with PAN OS.

The usage of a strict FIPS 140 Level 3 enabled Security World is supported with local cards only. RA cards are not supported in this version of PAN-OS. When using local cards with a strict FIPS 140 Level 3 world, the customer must create an OCS with no passphrase using a local card and present the local card in the front slot of the HSM. This OCS card will be used to provide FIPS authorization.

Non-FIPS world files are fully supported and do not require cards, as module protection is currently the only type of protection supported.

nShield Model	PAN OS Security World Client	Connect Image	Firmware	Security World Version	Non - Strict FIPS 140 Level 3	Strict FIPS 140 Level 3
nShield 5c	13.6.3	13.6.11	13.4.5 (FIPS 140-3 certified)	v3	Supported	Supported
Connect XC	13.6.3	13.6.11	12.72.1 and 12.72.3 (FIPS 140-2 certified)	v3	Supported	Supported

- Supported use cases: (Module protection Only)
 1. Firewall Master Key Protection
 2. SSL/TLS encrypt/decrypt (Inbound Inspection)
 3. SSL/TLS Outbound encrypt/decrypt (Forward Proxy)

1.2. Requirements

1.2.1. Before starting the integration process

Familiarize yourself with:

- *Installation Guide* and *User Guide* for your HSM.
- [Palo Alto Next Generation Firewall](#)

1.2.2. Before using Entrust hardware and software

The following preparations must be made before starting to use Entrust products:

- Each HSM uses a remote file system (RFS). You can configure the RFS on any computer running nShield Security World software. A HSM estate utilizes an RFS to store key objects and hsm configuration files for resilience and can be deployed on either a Windows or Linux host.
- A correct quorum for the Administrator Card Set (ACS).
 - For creating the Security World, determine who within the organization will act as custodians of the ACS.

-
- Obtain enough blank smart cards to create the Administrator Card Set (ACS).
 - Operator Card Set (OCS), Softcard, or Module-Only protection.
 - Module-Only protection is supported.
 - If OCS protection is utilized, it requires local cards with no passcode and a 1-of-N quorum.
 - Firewall configuration with usable ports:
 - 9004 for the HSM nfast server (hardserver).
 - 8200 for the Firewall.

Furthermore, the Security World parameters must be defined. For a detail of security implications of choices, see the *nShield Security Manual*:

- Whether your Security World must comply with FIPS 140 standards.
 - Currently FIPS 140-3 and 140-2 are supported with local cards, not remote cards.
 - If you are using FIPS 140-3 or 140-2, you must create a local OCS without a passphrase for FIPS authorization. This card must be presented on the front slot of the HSM. For information about limitations on FIPS authorization, see the *Installation Guide* of the nShield HSM.

Entrust recommends that you allow only unprivileged connections unless you are performing administrative tasks.

- Whether to instantiate the Security World as recoverable or not.

1.2.3. Before using the Palo Alto Networks Firewall

The following preparations must be made before starting to use the Palo Alto Networks Firewall:

- Obtain a Palo Alto Networks customer support account. This account requires access to the latest software releases.
- Procure a Palo Alto Networks Firewall appliance, or set up the Firewall in a bare-metal computer. A virtual machine (VM) can also be used. This guide was tested using a VMWare ESXi virtual machine.
- Upgrade the Firewall installation software with the latest package to be tested.
- The nShield RFS version must be compatible with the Palo Alto Networks Firewall, see [Product configurations](#).

1.3. Considerations for keys

Security Worlds that meet FIPS 140-3 standards require 2048-bit RSA keys.

Chapter 2. Procedures

The high-level procedure to install and configure a Palo Alto Network Firewall with an nShield HSM is as follows:

1. Set up the HSM and the security world.
2. Configure the Firewall to authenticate with the HSM(s).
3. Encrypt the master key on a Firewall and store it in the HSM.
4. Store the keys used for SSL forward proxy or SSL inbound inspection decryption.
5. Perform attestation that:
 - The master key is encrypted on the HSM.
 - The certificate use in SSL/TLS forward proxy is successfully imported into the Firewall.

2.1. Prepare the RFS and the HSM(s)

Each nShield HSM must have a remote file system (RFS) configured. The RFS includes master copies of all the files that the HSM requires, see the *User Guide* for your HSM.

If more than one HSM is used, they must use the same security world and be of the same type.

2.1.1. Upgrade the RFS software

To upgrade the RFS software:

1. Check the software version of the RFS by running the `ncversions` command.
2. If the software is older than **v12.60.11**, upgrade it. For instructions, see the *User Guide* for your HSM.

2.1.2. Create a security world on the RFS

At the RFS command prompt, run `new-world`.

For information on this command, see the *User Guide* for your HSM.


2.2. Set up connectivity between the Firewall, the HSM, and the RFS

2.2.1. Define connection settings for each HSM


The HSM authenticates the Firewalls based on their IP addresses. Therefore, you must configure the Firewalls to use static IP addresses. Dynamic addresses, assigned through DHCP, cannot be used.

If you want to set up connectivity to more than one HSM for high-availability, do it at this point. If more than one HSM is being used, the HSMs must share the same security world and be of the same type. For steps on loading an existing security world onto an HSM, see the *nShield Connect User Guide*. Adding more HSMs after the master key has been encrypted and stored in an HSM (see [Encrypt the master key using the HSM](#)) is only possible by first removing the master key from the HSM. The master key is required to perform the removal. Then encrypt and store the master key again in the HSM after adding new HSM to the list above.

1. Sign in to the Palo Alto Networks Firewall web interface and select **Device > Setup > HSM**.



2. Edit the **Hardware Security Module Provider** settings and set the **Provider Configured** to **Entrust nShield HSM**.
3. Add each HSM as follows. A high-availability HSM configuration requires at least two HSMs.
 - a. Enter a module name for the HSM. This can be any ASCII string of up to 31 characters.
 - b. Enter an IPv4 address for the HSM.
 - c. Repeat the first two steps for all HSMs.
4. Enter an IPv4 address for the RFS.
5. Select **OK**.



Hardware Security Module Details ⓘ

Provider Configured: **Entrust nShield HSM** ▼

MODULE NAME	SERVER ADDRESS
10079-12345-78901	10.0.0.1:443

+ Add - Delete


Remote Filesystem Address: 10.0.0.1:443

OK Cancel

6. Select the **Commit** icon, shown with a red arrow in the following picture.



7. Once committed, select **Close**. The HSM configuration should be displayed.



The screenshot shows the 'Hardware Security Module Details' configuration page. The 'Provider configured' field is set to 'Entrust nShield HSM'. The 'Remote Filesystem Address' is '10.0.0.1:443'. The 'Firewall Source Address' is '10.0.0.1:443'. The 'HSM Client Version on Firewall' is '12.6.3'. The 'Master Key Secured by HSM' checkbox is unchecked. The 'Status' is 'Not Authenticated'.

Hardware Security Operations

- Set Up Hardware Security Module
- Show Detailed Information
- Synchronize with Remote Filesystem
- Reset Configuration

Hardware Security Module Status

NAME	IP ADDRESS	MODULE STATE
10079-12345-78901	10.0.0.1:443	Not Authenticated

2.2.2. Configure a service route to the HSM

Perform these optional steps if you do not want the Firewall to connect through the default management interface. If you are connecting through the default management interface, go to [Register the Firewall as an HSM client](#).

1. Select **Device > Setup > Services > Service Route Configuration**.
2. Select **Customize a service route**.

The IPv4 tab is active by default.

3. For **Service**, select **HSM**.
4. Select a **Source Interface** for the HSM.
5. Select **OK**.
6. Select the **Commit** icon.

2.2.3. Register the Firewall as an HSM client

This can be done from the front panel of the HSM or from the RFS. These steps describe how to register the firewall as an HSM client from the RFS command line.

1. On the RFS, change to the HSM-specific directory to obtain the HSM configuration file and create a new configuration file:

```
cd /opt/nfast/kmdata/hsm-<HSM-ESN>/config/  
touch config.new  
cp config config.new
```

2. Edit **config.new**:

```
vi config.new
```

3. Add the following to the **[hs_clients]** section:

```
addr=<Firewall-IP>  
clientperm=unpriv  
keyhash=0000000000000000000000000000000000000000000000000000000000000000  
esn=  
timelimit=0  
datalimit=0  
-----
```

4. Push **config.new** to the HSM:

```
cfg-pushnethsm --address=<HSM-IP> config.new
```

5. Check the **config** file for the changes made: (there should be no differences)

```
diff config.new config
```

6. Repeat these steps for each HSM in the high-availability configuration.

2.2.4. Configure the RFS to accept connections from the Firewall and the HSM

The assumption here is the RFS is running on Linux.

To configure the RFS to accept connections from the Firewall and the HSM:

1. Sign in to the RFS.
2. Assume root privileges by running the **su** command:

```
su
```

3. Configure or disable the RFS firewall:

```
service firewalld stop
```



The RFS firewall is independent of the Palo Alto Networks Firewall. An RFS reboot re-enables the RFS firewall.

4. Verify that the RFS firewall stopped:

```
service firewalld status
```

5. Set up the RFS. The following command must be run for each HSM being added to your high-availability configuration:

```
rfs-setup --force <HSM_IP_address> $(anonkneti <HSM_IP_address>)
```

6. Run the following command to permit HSM client submissions on the RFS:

```
rfs-setup --gang-client --write-noauth <Firewall-IP-address>
```

You can use the following commands to configure the RFS to accept connections from the client Firewall. **rfs-setup** is run on the RFS. **rfs-sync** is run on the client.

```
RFS    rfs-setup --gang-client --write-noauth --force <client_IP_address>
Client rfs-sync --setup --no-authenticate <RFS_IP_Address>
       rfs-sync --update
       rfs-sync --commit
```

For security reasons, the Firewall has a protected command-line interface that does not allow direct access to **rfs-setup** and **rfs-sync** in its built-in nfast server. Instead, equivalent commands are available in the protected Palo Alto Networks Firewall command-line interface and can be useful for debugging.

nShield Command	Palo Alto Networks Command
<code>/opt/nfast/bin/rfs-sync --setup --no-authenticate <RFS_IP_Address></code>	<code>request hsm rfs-setup</code>

nShield Command	Palo Alto Networks Command
/opt/nfast/bin/rfs-sync --update	request hsm rfs-sync
/opt/nfast/bin/rfs-sync --commit	
/opt/nfast/bin/enquiry	show hsm info

2.2.5. Authenticate the Firewall to the HSM

To authenticate the Firewall to the HSM:

1. In the Palo Alto Networks Firewall web interface, select **Device > Setup > HSM > Setup Hardware Security Module**.

A confirmation dialog appears. For the **Enroll Hardware Security Module**, select one of the HSMs.

Confirm ?

Enroll Hardware Security Module


Server Name SELECT SERVER FROM...

OK

Cancel

2. Select **OK**.

The Firewall authenticates to the HSM and displays a completion message:

	Type	Response	Status
	Enroll Hardware Security Module	Enrolled with server nShield successfully	success

OK


3. Select **OK**.

2.2.6. Synchronize the Firewall with the RFS

To synchronize the Firewall with the RFS:

1. In the Palo Alto Networks Firewall web interface, select **Device > Setup > HSM > Synchronize with Remote Filesystem**.

The Firewall synchronizes with the RFS and displays a completion message:




OK

2. Select **OK**.

2.2.7. Verify Firewall connectivity and authentication with the HSM

To verify Firewall connectivity and authentication with the HSM:


1. In the Palo Alto Networks Firewall web interface, select **Device > Setup > HSM**.
2. Check the **Hardware Security Module Status**. It should show **Authenticated**.
 - **Name** - The name of the HSM.
 - **IP address** - The IP address of the HSM.
 - **Module State** - The current state of the HSM connection: **Authenticated** or **NotAuthenticated**.



3. Check the connection status:
 - **Green** - The Firewall is successfully authenticated and connected to the HSM.
 - **Red** - The Firewall failed to authenticate to the HSM, or network connectivity to the HSM is down.

A left-over **rfs-sync** lock from a failed attempt could cause red status. Launch a command-line interface on the RFS, remove the **/opt/nfast/kmdata/local/.nft-lock** file, then re-run the instructions in [Synchronize the Firewall with the RFS](#).

4. Finally, select **Device > Setup > HSM > Show Detailed Information**. This is equivalent to running **enquiry** on the firewall.



2.3. Encrypt the master key using the HSM

A master key encrypts all private keys and passwords on the Palo Alto Networks Firewall. Every time the Firewall is required to decrypt a password or private key, it requests the HSM to decrypt the master key.

The HSM encrypts the master key using a wrapping key. To maintain security, you must occasionally change (refresh) this wrapping key.

2.3.1. Encrypt the master key

Use this procedure for first time encryption of a key, or if you define a new master key and you want to encrypt it.

1. In the Palo Alto Networks Firewall web interface, select **Device > Master Key and Diagnostics**.
2. Select the gear icon next to **Master Key**.
3. Select the **Master Key** check box.
4. For **Current Master Key**, enter the key that is currently used to encrypt all of the private keys and passwords on the Firewall (if applicable).
5. Select the **Stored on HSM** check box.
6. Enter the new master key and confirm.
7. Enter the following information:
 - **Life Time** - The number of days and hours after which the master key expires (1-18250 days).

- **Time for Reminder** - The number of days and hours before expiration when the user is notified of the impending expiration (1-365 days).

Master Key

☒ Master Key

Current Master Key

☒ Stored on HSM

New Master Key

Confirm New Master Key

Lifetime

Days Hours

Ranges from 1 hour to 18250 days.

Time for Reminder

Days Hours

Ranges from 1 hour to 365 days.

☐ Auto Renew Master Key

Auto Renew With Same Master Key

Days Hours

Ranges from 1 hour to 730 days.

OK
Cancel

8. Select **OK** and then select **Commit**.

The **Master Key** information is updated.

Master Key

Stored on HSM

☒

Lifetime

18249 days 23 hours 59 minutes

Time for Reminder

30 days 0 hours 0 minutes

Auto Renew With Same Master Key

The new key is also visible in **Device > Setup > HSM > Hardware Security Module Details**.

Hardware Security Module Details

Provider configured

Entrust nShield HSM

Remote Filesystem Address

10.10.10.10

Firewall Source Address

10.10.10.10

HSM Client Version on Firewall

13.6.3

Master Key Secured by HSM

☒

Status

●

9. Sync the newly created Master Key to the RFS.

Select **Device > Setup > HSM > Synchronize with Remote Filesystem**.

A pop-up should appear saying **HSM rfs sync done**.

You should see the newly created in key in **/opt/nfast/kmdata/local** in the RFS.

```
% cd /opt/nfast/kmdata/local
% ls -al key_*
-rw-r--r--. 1 nfast nfast 7040 Aug 26 14:19 key_pkcs11_ua210478667b71fd9d55ef10a2d3d2f21b681a03dd
```

2.3.2. Refresh the master key encryption

Refresh the master key encryption by rotating the wrapping key that encrypts it. The wrapping key resides on the HSM.

1. Sign in to the Palo Alto Networks Firewall command-line interface.
2. Use the following command to rotate the wrapping key for the master key on an HSM:

```
request hsm mkey-wrapping-key-rotation
```

For example:

```
admin@PA-VM> request hsm mkey-wrapping-key-rotation
Mkey wrapping key rotation succeeded. New key handle 1119.
admin@PA-VM>
```

The **mkey-wrapping-key-rotation** command does not delete the old wrapping key.

- If the master key is encrypted on the HSM, the command generates a new wrapping key on the HSM and encrypts the master key with the new wrapping key.
- If the master key is not encrypted on the HSM, the command generates a new wrapping key on the HSM for future use.

3. Sync the newly created Key to the RFS.

Select **Device > Setup > HSM > Synchronize with Remote Filesystem**.

A pop-up should appear saying **HSM rfs sync done**.

You should see the newly created in key in **/opt/nfast/kmdata/local** in the RFS.

```
% cd /opt/nfast/kmdata/local
% ls -al key_*
-rw-r--r--. 1 nfast nfast 7040 Aug 26 14:19 key_pkcs11_ua210478667b71fd9d55ef10a2d3d2f21b681a03dd
-rw-r--r--. 1 nfast nfast 7040 Aug 26 14:20 key_pkcs11_uaac73f6835c0efe822f6add4ad1cffc0fec60963b
```

2.4. Store the key used in SSL/TLS decryption

The HSM can be used to securely store the private keys used in SSL/TLS decryption for:

- **SSL forward proxy** - Store the private key of the Forward Trust certificate that signs certificates in SSL/TLS forward proxy operations. The Firewall will then send the certificates that it generates during such operations to the HSM for signing before forwarding these to the clients.

- **SSL inbound inspection** - Store the private keys for the internal servers for which it is performing SSL/TLS inbound inspection.

2.4.1. Generate a self-signed certificate and key

This section describes a method to generate a self-signed certificate and key for purposes of this guide using the HSM. This is the preferred method to generate such key and certificate. For information about importing existing keys and certificates, see the *User Guide* for your HSM.

The HSM **generatekey** command generates a key file with the same syntax as an RSA private key file, but contains the key identifier rather than the key itself, which remains protected in the HSM.

1. Sign in to the RFS.
2. Assume root privileges by running the **su** command:

```
su
```

3. Run the **generatekey** command:

```
cd /opt/nfast/kmdata/local
generatekey pkcs11 selfcert=yes
```

Currently, only module protected keys are supported. For example:

```
[root@red_hat_8_rfs local]# generatekey pkcs11 selfcert=yes
module: Module to use? (1, 2) [1] >
protect: Protected by? (token, softcard, module) [token] > module
recovery: Key recovery? (yes/no) [yes] >
type: Key type? (DES3, DH, DHEX, DSA, HMACSHA1, HMACSHA256, HMACSHA384,
HMACSHA512, RSA, DES2, AES, Rijndael, Ed25519, X25519) [RSA]
>
size: Key size? (bits, minimum 1024) [2048] >
OPTIONAL: pubexp: Public exponent for RSA key (hex)? []
>
plainname: Key name? [] > paloaltoss1
x509country: Country code? [] > US
x509province: State or province? [] > FL
x509locality: City or locality? [] > Sunrise
x509org: Organization? [] > SWTesting
x509orgunit: Organization unit? [] > InterOp
x509dnscommon: Domain name? [] > paloaltofirewall
x509email: Email address? [] > test@test.com
nvrnm: Blob in NVRAM (needs ACS)? (yes/no) [no] > no
digest: Digest to sign cert req with? (md5, sha1, sha256, sha384, sha512)
[default sha256] >
key generation parameters:
operation      Operation to perform      generate
application    Application                  pkcs11
module          Module to use                  1
```

```

protect      Protected by      module
recovery     Key recovery      yes
verify       Verify security of key  yes
type         Key type         RSA
size         Key size         2048
pubexp       Public exponent for RSA key (hex)
plainname    Key name          HSMKey
x509country  Country code       US
x509province State or province  FL
x509locality City or locality   Sunrise
x509org      Organization       SWTesting
x509orgunit  Organization unit  InterOp
x509dnscommon Domain name        paloaltofirewall
x509email    Email address      test@test.com
nvram        Blob in NVRAM (needs ACS)  no
digest       Digest to sign cert req with sha256

Please wait.....
Key successfully generated.
Path to key: /opt/nfast/kmdata/local/key_pkcs11_ua5efdb72cb623c41d6ec9baeacc1eac95be8ada2b
Path to self-cert: /opt/nfast/kmdata/local/pkcs11_ua5efdb72cb623c41d6ec9baeacc1eac95be8ada2b_selfcert
[root@red_hat_8_rfs local]#

```

- a. If you selected **token** for OCS protection, you must provide the OCS 1/N quorum for **fips-auth** when a strict FIPS 140 Level 3 world is used. If you provide the ACS quorum, the **generatekey** command will fail.

Token (OCS) protection is not currently supported.

- b. If you selected **module** for module protection, you must provide the OCS 1/N quorum to provide **fips-auth** for this HSM operation when a strict FIPS 140 Level 3 world is used.
4. Two files are created. The key file has the same syntax as an RSA private key file, but actually contains the key identifier rather than the key itself, which remains protected. The file type and naming are:

File Type	Naming
Key file (key identifier rather than the key itself)	key_pkcs11_...
Self-signed certificate	pkcs11_..._selfcert

5. You can view the content of the certificate created above by viewing the self-signed certificate (**.crt**):

```

openssl x509 -text -noout -in
/opt/nfast/kmdata/local/pkcs11_ua5efdb72cb623c41d6ec9baeacc1eac95be8ada2b_selfcert

```

2.4.2. Synchronize the key data from the RFS to the Firewall

To synchronize the key data from the RFS to the Firewall:

1. In the Palo Alto Networks Firewall web interface and select **Device > Setup > HSM**.
2. In the **Hardware Security Operations** settings, select **Synchronize with Remote Filesystem**.

The Firewall confirms when the synchronization is complete.

2.4.3. Import the certificate that corresponds to the HSM-stored key into the Firewall

To import the certificate that corresponds to the HSM-stored key into the Firewall:

1. Sign in to the Palo Alto Networks Firewall web interface from the RFS.
2. Launch the browser from the RFS to be able to upload files from the RFS files system to the Palo Alto Networks Firewall.
3. Select **Device > Certificate Management > Certificates > Device Certificates**
4. Select **Import**.
5. For **Certificate Type**, select the **Local** option.
6. Enter the **Certificate Name**.
7. Browse to the Certificate File on the RFS. This is the file ending in **_selfcert** from the certificate generated in the previous step.

`/opt/nfast/kmdata/local/pkcs11_ua5efdb72cb623c41d6ec9baeacc1eac95be8ada2b_selfcert`

8. From the **File Format** list, select **Base64 Encoded Certificate (PEM)**.
9. Select the **Private key resides on Hardware Security Module** check box.

Import Certificate ⓘ

Certificate Type: ☒ Local ☐ SCEP ☐ Cloud

Certificate Name:

File Format: ▼

Certificate File: [Browse...](#)

☒ Private key resides on Hardware Security Module

☐ Import Private Key

☐ Block Private Key Export

Key File: [Browse...](#)

Passphrase:

Confirm Passphrase:

10. Select **OK**.
11. Select the **Commit** icon and close the dialog.

A new certificate has been imported:


Custom Certificates Default Trusted Certificate Authorities PAN-OS System Certificates Cached Intermediate Certificates									
Q									
<input type="checkbox"/>	NAME	SUBJECT	ISSUER	CA	KEY	EXPIRES	STATUS	ALGORITHM	USAGE
<input type="checkbox"/>	TL3v1.3_Default	C=US, ST=CA, L=...	C=US, ST=CA, L=...			Aug 19 15:25:04 20...	valid	Elliptic Curve DSA	
<input type="checkbox"/>	PaloAltoSchModule	C=US, ST=FL, L=...	C=US, ST=FL, L=...			Sep 19 17:57:29 20...	valid	RSA	

Under the **KEY** column, you should see a lock symbol, indicating the private key for the certificate is on the HSM. If you see an error symbol, either the private key is not on the HSM or the HSM is not properly authenticated or connected.

2.4.4. Enable the certificate for use in SSL/TLS forward proxy

To enable the certificate for use in SSL/TLS forward proxy:

1. In the Firewall web interface, open the certificate that you have imported: select **Device > Certificate Management > Certificates > Custom Certificates**.
2. Select the certificate to open it.
3. Select the **Forward Trust Certificate** check box.




4. Select **OK**.
5. Commit your changes.

The **USAGE** column now shows **Forward Trust Certificate**.

2.4.5. Verify the certificate import into the Firewall

To verify the certificate import into the Firewall:

1. Locate the certificate that you imported.




2. Check the icon in the **KEY** column:
 - **Lock icon** — The private key for the certificate is on the HSM.
 - **Error icon** — The private key is not on the HSM or the HSM is not properly authenticated or connected.
3. Check the **USAGE** column. It should show **Forward Trust Certificate**.

2.5. Adding more HSMs

Adding more HSMs after the master key has been encrypted and stored in an HSM (see [Encrypt the master key using the HSM](#)) is only possible by first removing the master key from the HSM. The master key is required to perform the removal. Then encrypt and store the master key again in the HSM after adding a new HSM. Any new HSMs that are added must share the same security world being used.

1. On the Firewall GUI, select **Device > Master Key and Diagnostics**.
2. Select the gear icon next to **Master Key**.
3. Enter the current master key and **uncheck** the box for **Stored on HSM**.
4. You can keep the same master key or make a new one temporarily. This is just the intermediate step to remove the key from the HSM so more HSMs can be added.
5. Select **OK** and select **Commit**.



6. Go to **Device > Setup > HSM** and select the gear icon next to ***Hardware Security Module Details**.
7. In the **Hardware Security Module Details** Dialog:

- a. In the **Provider Configured** dropdown, select **Entrust nShield HSM**.
- b. Select **Add** and enter a name for the module, like **nShield XC**.
- c. Under **Server Address**, enter the IP address of the HSM.
- d. In the **Remote Filesystem Address** field, enter the IP address of the RFS, then select **OK**.

Hardware Security Module Details ?

Provider Configured

Entrust nShield HSM

MODULE NAME	SERVER ADDRESS
Module Name 1	10.10.10.10
Module Name 2	10.10.10.10

+ Add
- Delete

Remote Filesystem Address

10.10.10.10

OK

Cancel

8. Select the **Commit** button in the top right of the GUI to apply the configuration to the firewall.

Commit ?

Doing a commit will overwrite the running configuration with the commit scope.

• Commit All Changes
 ☐ Commit Changes Made By: (1) admin

COMMIT SCOPE	LOCATION TYPE	OBJECT TYPE	ENTITIES	ADMINS
▶ device-and-network	Device and Network Configuration			

Preview Changes
 Change Summary
 Validate Commit


Note: This shows all the changes in login admin's accessible domain.

Description

Commit

Cancel

9. Wait until it is committed.




10. Select **Close**.


11. You should be sharing the same security world across all of the HSMs.

12. In the PanOS WebGUI, select **Device > Setup > HSM > Set Up Hardware Security Module**.


A confirmation dialog appears. For the **Enroll Hardware Security Module**, select one of the HSMs.




Select **OK**. The firewall attempts to authenticate to the HSM. Make sure the status message that is displayed shows the authentication was successful.



You should see both HSMs where the **MODULE STATE** is **Authenticated**.



13. Synchronize the firewall with the RFS. Select **Device > Setup > HSM > Synchronize with Remote Filesystem**. A pop-up should appear saying **HSM rfs sync done**.



14. When you have finished adding HSMs, re-create the master key, selecting the checkbox for **Stored on HSM**. This will encrypt the new master key and store it with multiple HSMs configured.

Chapter 3. Additional resources and related products

3.1. nShield Connect

3.2. nShield as a Service

3.3. Entrust products

3.4. nShield product documentation